

	M SERIES SPARE PARTS
1	CASING WITH STUDS
2	BEARING HOUSINGS (BARE)
3	IMPELLERS
4	
5	SHAFT SLEEVES/BUSHING
6	IMPELLER KEY
7	IMPELLER NUT
8	MECHANICAL SEAL
9	CASING GASKET
23	BEARING HOUSING PARTS
25	CIRCLIP
	SHAFTS

